

## Client Independent Visualization Switching



The CODESYS Package contains an example project which shows how to switch visualizations of different display variants independently.

### Product Description

---

The example project switches the visualizations of all TargetVisu display variants every second. The visualization of WebVisu display variants will not be switched.

### Range of Functions

---

The program `VisuHandling` controls the switching of the visualizations. The call `VisuElems.g_ClientManager.GetNextClient()` gets the next active display variant. The visualization of all TargetVisu display variants will be switched every second. It is important that the program `VisuHandling` is called via the visualization task.

## General Information



|                          |  |
|--------------------------|--|
| <b>Supplier</b>          | 3S-Smart Software Solutions GmbH<br>Memminger Straße 151<br>87439 Kempten<br>Deutschland |
| <b>Support</b>           | Tel: +49 831 54031 66<br>support@codesys.com   |
| <b>Product</b>           | Client Independent Visualization Switching   |
| <b>Order Number</b>      | 000070   |
| <b>Sales</b>             | CODESYS Store<br>store.codesys.com   |
| <b>Scope of Delivery</b> | CODESYS Package with example project   |

## System Requirements and Restrictions

|                                      |   |
|--------------------------------------|---|
| <b>Programming System</b>            | CODESYS Development System V3.5.6.0   |
| <b>Target System</b>                 | CODESYS Control V3.5.6.0  |
| <b>Supported Platforms / Devices</b> | All<br>Notice: Use the project 'Device Reader' to find out the supported features of your device. 'Device Reader' is available for free in the CODESYS Store. |
| <b>Additional Requirements</b>       | -   |
| <b>Restrictions</b>                  | -   |
| <b>Licensing</b>                     | No license required   |
| <b>Required Accessory</b>            | -   |